

Procedure
Video Camera
Revised April 18, 2006

1. Charge battery before using – battery is not in camera when charging. Or you can use the camera by plugging it into an electric outlet (without battery). Takes three hours to charge.
2. Set dial to green rectangle, remove lens cap.
3. Slide Off/VCR/Camera switch to “Camera.”
4. Load cassette.
5. Unlock.
6. Hit red button on top to record.
7. To zoom, toggle on top.
8. To playback, slide switch to VCR and push buttons in handle.
9. Use camera with tape to create DVD. SW=Studio
10. REMOVE BATTERY WHEN DONE.